



STANDS COORDINATES (WGS 84)

1	11°44'59.05"N	108°22'02.91"E	7	11°44'59.57"N	108°22'12.85"E
1R	11°44'59.04"N	108°22'02.72"E	8	11°44'59.67"N	108°22'14.73"E
2	11°44'59.09"N	108°22'04.29"E	8R	11°45'00.74"N	108°22'14.08"E
3	11°44'59.18"N	108°22'06.14"E	8L	11°45'00.80"N	108°22'15.25"E
4	11°44'59.29"N	108°22'07.62"E	9	11°44'59.77"N	108°22'16.60"E
5	11°44'59.39"N	108°22'09.37"E	9A	11°45'00.87"N	108°22'16.54"E
5R	11°44'59.93"N	108°22'09.10"E	10	11°45'02.01"N	108°22'35.78"E
6	11°44'59.47"N	108°22'10.85"E	11	11°45'00.66"N	108°22'35.85"E

LEGEND

BUILDING	■
AIRCRAFT STAND	5
TAXIWAY LIGHT	•
RWY – HOLDING POSITION	≡≡≡
STOP BAR	●●●

NOTES:

- STANDS NR 8R, NR 8L AND NR 9A ARE FOR ACFT UP TO CODE B AND EQUIVALENT (WINGSPAN UP TO BUT NOT INCLUDING 24M).
- STAND NR 8R IS ONLY USED WHEN THERE IS NO ACFT PARKING AT STAND NR 8.
- STAND NR 8L IS ONLY USED WHEN THERE IS NO ACFT PARKING AT STAND NR 8.
- STAND NR 8 IS ONLY USED WHEN THERE IS NO ACFT PARKING AT STAND NR 8R, 8L.
- STAND NR 9A IS ONLY USED WHEN THERE IS NO ACFT PARKING AT STAND NR 9.
- STAND NR 9 IS ONLY USED WHEN THERE IS NO ACFT PARKING AT STAND NR 9A
- OPERATIONAL PROCEDURES: REFERS TO TEXTUAL SECTION FOR DETAILS.